



Martin-Till®

PLANTER ATTACHMENT GUIDE

This guide was compiled with current specifications obtained from U.S. planter manufacturers.

To ensure proper application for your specific planter setup, you are encouraged to call our sales office (270-265-5817) for assistance.

You may add a Z to any part number to replace Spading Wheels with Razor Wheels

Dual UMO Fertilizer Openers are available for most planters—Call for details

Martin Row Cleaners require the following dimensions from the face plate of planter unit:

Floating Models	Distance Needed from Face Plate
BD1360 & BKW1360	19"
BDC1360 & BKC1360	22"
BD/UMO1360 & BKW/UMO1360	25"
BD/DUMO1360 & BKW/DUMO 1360	30"
BCIH1360	22"
C125S & C125S-XP	19 1/2"
C125R & C125R-XP	25"
C125MTL	27 1/2"
C125MTXL	30"
C125S-IH	22 1/2"
C125R-IH	25 3/4"
Rigid Pin-Adjust Models	
B1332	9"
B1532	10"
B1320	12 1/2"



Planter Model JD 1710

VERTICAL FOLD

***Note: Will not work next to wheel modules**

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
Standard parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust BD/UMO1360 Fertilizer opener/ row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK01
Standard parallel arms, with no-till coulters, w/o fertilizer openers	BDC1360 Floating C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, with no-till coulters, with frame mounted fertilizer openers	No row cleaner will work	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust BD/UMO1360 Fertilizer opener/row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, w/o fertilizer openers	BDC1360 Floating C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, with frame mounted fertilizer openers	BDC1360 Floating	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted double disk fertilizer openers	BDD1360 Floating C125 Floating With C125MTL-XP Mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted single disk fertilizer injector coulters	C125 Floating With C125MTXL-XP Mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01

Planter Model JD 1720

STACK FOLD

***Note: Will not work next to wheel modules**

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
Standard parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK01
Standard parallel arms, with no-till coulters, w/o fertilizer openers	BDC1360 Floating C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, with no-till coulters, with frame mounted fertilizer openers	No row cleaner will work	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, w/o fertilizer openers	BDC1360 Floating C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, with frame mounted fertilizer openers	BDC1360 Floating	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted double disk fertilizer openers	BDD1360 Floating C125 Floating With C125MTL-XP mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted single disk fertilizer injector coulters	C125 Floating With C125MTXL-XP mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01

Planter Model JD 1750

***Note 1: If drive shaft is under frame, floating row cleaners will require SG-01 shaft guard**

****Note 2: Will not work next to wheel modules**

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
Standard parallel arms, w/o no-till coulters, w/o fertilizer openers	*BD1360 Floating *C125S-XP Floating B1332/772 Pin adjust **B1532/772 Pin adjust *BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK01
Standard parallel arms, with no-till coulters, w/o fertilizer openers	*BDC1360 Floating *C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	*BD1360 Floating *C125S-XP Floating B1332/772 Pin adjust **B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, with no-till coulters, with frame mounted fertilizer openers	No row cleaner will work	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, w/o fertilizer openers	*BD1360 Floating *C125S-XP Floating B1332/772 Pin adjust **B1532/772 Pin adjust *BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, w/o fertilizer openers	*BDC1360 Floating *C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms w/o no-till coulters, with frame mounted fertilizer openers	*BD1360 Floating *C125S-XP Floating B1332/772 Pin adjust **B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, with frame mounted fertilizer openers	*BDC1360 Floating	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted double disk fertilizer openers	*BDD1360 Floating *C125 Floating With C125MTL-XP mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted single disk fertilizer injector coulters	*C125 Floating With C125MTXL-XP mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01

Planter Model JD 1760

FOLDING

***Note: Will not work next to wheel modules**

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
Standard parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK01
Standard parallel arms, with no-till coulters, w/o fertilizer openers	BDC1360 Floating C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, with no-till coulters, with frame mounted fertilizer openers	No row cleaner will work	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, w/o fertilizer openers	BDC1360 Floating C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, with frame mounted fertilizer openers	BDC1360 Floating	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted double disk fertilizer openers	BDD1360 Floating C125 Floating With C125MTL-XP mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted single disk fertilizer injector coulters	C125 Floating With C125MTXL-XP mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01

Planter Model JD 1770 NT

***Note: Will not work next to wheel modules**

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
Standard parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK01
Standard parallel arms, with no-till coulters, w/o fertilizer openers	BDC1360 Floating C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, with no-till coulters, with frame mounted fertilizer openers	No row cleaner will work	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, w/o fertilizer openers	BDC1360 Floating C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, with frame mounted fertilizer openers	BDC1360 Floating	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted double disk fertilizer openers	BDD1360 Floating C125 Floating With C125MTL-XP mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted single disk fertilizer injector coulters	C125 Floating With C125MTXL-XP mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01

Planter Model JD 1780

***Will not work next to wheel modules**

****Will not work behind transport tire**

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
Standard parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust **BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK01
Standard parallel arms, with no-till coulters, w/o fertilizer openers	**BDC1360 Floating **C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, with no-till coulters, with frame mounted fertilizer openers	No row cleaner will work	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust **BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, w/o fertilizer openers	**BDC1360 Floating **C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	**BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, with frame mounted fertilizer openers	*BDC1360 Floating	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01

Planter Model JD 1790

FRONT ROWS

***Note: Will not work next to wheel modules**

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
Standard parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK01
Standard parallel arms, with no-till coulters, w/o fertilizer openers	BDC1360 Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Standard parallel arms, with no-till coulters, with frame mounted fertilizer openers	No row cleaner will work	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, w/o fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, w/o fertilizer openers	BDC1360 Floating C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, w/o no-till coulters, with frame mounted fertilizer openers	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulters, with frame mounted fertilizer openers	BDC1360 Floating	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted double disk fertilizer openers	BDD1360 Floating C125 Floating With C125MTL-XP mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with unit mounted single disk fertilizer injector coulters	C125 Floating With C125MTXL-XP mount	Does not apply	BSCW1344 Dual BSCW1544 Single	DCK-01

Planter Model JD 1790

REAR ROWS

***Note 1: Will not work next to wheel modules**

****Note 2: Planter must be equipped with double crop package**

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
Standard parallel arms , w/o no-till coulters	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust ** BD/UMO1360 Row cleaner fert opener combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK01
Standard parallel arms, with no-till coulter	**BDC1360 Floating	Will not work with coulter	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms , w/o no-till coulter	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust *B1532/772 Pin adjust **BD/UMO1360 Row cleaner fert opener combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	DCK-01
Extended parallel arms, with no-till coulter	**BDC1360 Floating **C125R-XP Floating	Will not work with coulter	BSCW1344 Dual BSCW1544 Single	DCK-01

Planter Model JD DB

BAUER BUILT BAR

***Note 1: Planters with optional transport tires may experience interference issues with floating row cleaners**

****Note 2: Will not work behind transport tires**

Row Cleaner & Mount

Fertilizer Opener

Spiked Closing Wheels

RID-01

Drag Chain

Standard parallel arms, w/ o no-till coulters	*BD1360 Floating *C125S-XP Floating B1332/772 Pin adjust B1532/772 Pin adjust	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	RID-01 XP units require A56621 inner rim	DCK-01
Standard parallel arms, with no-till coulters	**BDC1360 Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	RID-01 XP units require A56621 inner rim	DCK-01
Extended parallel arms, w/o no-till coulters	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust B1532/772 Pin adjust BD/UMO1360 Fert opener row cleaner combo	UMO-100 Requires UMO-MTJ mount	BSCW1344 Dual BSCW1544 Single	RID-01 XP units require A56621 inner rim	DCK-01
Extended parallel arms, with no-till coulters	BDC1360 Floating C125R-XP Floating	Will not work with coulters	BSCW1344 Dual BSCW1544 Single	RID-01 XP units require A56621 inner rim	DCK-01

**Planter Models JD 7000—7100
JD 7200—7300**

Note: If drive shaft is under planter frame, floating row cleaners will require SG-01 shaft guard

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
7000 & 7100 w/o coulter	BKW1360 Floating C125S Floating B1332/772 Pin adjust B1532/772 Pin adjust BKW/UMO1360 Fert opener row cleaner combo	UMO-100 with UMO-MTA mount	BSCW1341 Dual BSCW1541 Single	DCK-01
7000 & 7100 with unit mounted no-till coulter	C125R Floating	Will not work with coulter	BSCW1341 Dual BSCW1541 Single	DCK-01
7200 & 7300 w/o coulter	BD1360 Floating C125S-XP Floating B1332/772 Pin adjust B1532/772 Pin adjust BD/UMO1360 Fert opener row cleaner combo	UMO-100 with UMO-MTJ mount	BSCW1343 Dual BSCW1543 Single	DCK-01
7200 & 7300 with unit mounted no-till coulter	BDC1360 Floating C125R-XP Floating	Will not work with coulter	BSCW1343 Dual BSCW1543 Single	DCK-01

Planter Model **KINZE**

If planter has pneumatic down pressure, USB-7AB bracket is required with USB-70

***Note: USB-70 Set back bracket required on 4 center rows**

****Note: USB-70 Set back bracket required on all center rows**

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
2000 & 3000 Series w/o Coulters	BKW1360 Floating C125S Floating B1332/772 Pin adjust B1532/772 Pin adjust BKW/UMO1360 Fert opener row cleaner combo	UMO/100 with UMO-MTA mount	BSCW1344 Dual BSCW1544 Single	DCK-01
2000 & 3000 Series with unit mounted no-till coulter	BKC1360 C125R Floating	Will not work with coulter	BSCW1344 Dual BSCW1544 Single	DCK-01
2200 & 3200 Econo fold w/o coulters	BKW1360 Floating C125S Floating B1332/772 Pin adjust B1532/772 Pin adjust BKW/UMO1360 Fert opener row cleaner combo	UMO/100 with UMO-MTA mount	BSCW1344 Dual BSCW1544 Single	DCK-01
2200 & 3200 Econo fold with unit mounted no-till coulters	BKC1360 C125R Floating	Will not work with coulter	BSCW1344 Dual BSCW1544 Single	DCK-01
2500 & 3500 Series Twin Line w/o coulter	BKW1360 Floating C125S Floating B1332/772 Pin adjust B1532/772 Pin adjust *BKW/UMO1360 Fert opener row cleaner combo	UMO/100 with UMO-MTA mount	BSCW1344 Dual BSCW1544 Single	DCK-01
2500 & 3500 Series Twin Line with unit mounted no-till coulter	*BKC1360 *C125R Floating	Will not work with coulter	BSCW1344 Dual BSCW1544 Single	DCK-01
2600 & 3600 Series Twin Line w/o coulter	BKW1360 Floating C125S Floating B1332/772 Pin adjust B1532/772 Pin adjust *BKW/UMO1360 Fert opener row cleaner combo	UMO/100 with UMO-MTA mount	BSCW1344 Dual BSCW1544 Single	DCK-01
2600 & 3600 Series Twin Line with unit mounted no-till coulter	*BKC1360 *C125R Floating	Will not work with coulter	BSCW1344 Dual BSCW1544 Single	DCK-01
3700 & 3800 Series Front Fold w/o coulter	BKW1360 Floating C125S Floating B1332/772 Pin adjust B1532/772 Pin adjust **BKW/UMO1360 Fert opener row cleaner combo	UMO/100 with UMO-MTA mount	BSCW1344 Dual BSCW1544 Single	DCK-01
3700 & 3800 Series Front Fold with unit mounted coulter	**BKC1360 Floating **C125R Floating	Will not work with coulter	BSCW1344 Dual BSCW1544 Single	DCK-01

Planter Model KINZE

***Note: Will not work with pneumatic down pressure**

****Note: Will not work with frame mounted fertilizer openers**

Row Cleaner & Mount

Fertilizer Opener

Spiked Closing Wheels

Drag Chain

<p>4900 w/o no-till coulters</p>	<p>BK41360 Floating Row Cleaner</p> <p>BK4/UMO1360 Row Cleaner/Fertilizer Opener Combo</p> <p>*B1332/4772 Pin Adjust Row Cleaner</p> <p>*B1532/4772 Pin Adjust Row Cleaner</p>	<p>UMO/100 with MT1360K4U-mount</p>	<p>BSCW1344 Dual BSCW1544 Single</p>	<p>DCK-01</p>
<p>4900 with unit mounted coulters</p>	<p>**BK4C1360</p>	<p>Will not work with coulters</p>	<p>BSCW1344 Dual BSCW1544 Single</p>	<p>DCK-01</p>

Planter Model **WHITE**

***Note: Will not work if drive shaft is under frame**

****Note: Will not work with pneumatic down pressure**

*****Note: Will not work with recessed H bracket**

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
5100 Series	B1332/512 Pin adjust B1532/512 Pin adjust	Will not work	BSCW51	Does not apply
6000 Series with standard down pressure w/o coulter Early model	*BKW1360 Floating *C125S Floating B1332/772 Pin adjust B1532/772 Pin adjust *BKW/UMO1360 Fert opener row cleaner combo	UMO-100 with UMO-MTA mount	Double V system uses BSCW1344 Dual BSCW1544 Single ***Single tire uses BSCW61	Double V closing system uses DCK-01 Does not apply on Single tire system
6000 Series with standard down pressure with unit mounted no-till coulter Early model	*C125R Floating	Will not work with coulter	Double V system uses BSCW1344 Dual BSCW1544 Single ***Single tire uses BSCW61	Double V closing system uses DCK-01 Does not apply on Single tire system
6000 Series with heavy duty down pressure w/o coulter Early model	*BKW1360 Floating *C125S Floating B1332/610 Pin adjust B1532/810 Pin adjust BKW/UMO1360 fert opener row cleaner combo	UMO-100 with UMO-MTA mount	Double V system uses BSCW1344 Dual BSCW1544 Single ***Single tire uses BSCW61	Double V closing system uses DCK-01 Does not apply on Single tire system
6000 Series with heavy duty down pressure with unit mounted no-till coulter Early model	*C125R Floating	Will not work with coulter	Double V system uses BSCW1344 Dual BSCW1544 Single ***Single tire uses BSCW61	Double V closing system uses DCK-01 Does not apply on Single tire system
Late 6000 & 8000 Series w/o coulter	*BKW1360 Floating **B1332/810 Pin adjust **B1532/772 Pin adjust *BKW/UMO1360 Fert opener row cleaner combo	UMO-100 with UMO-MTW mount	BSCW1344 Dual BSCW1544 Single Note—not available for 8000 single wheel closing system	Double V closing system uses DCK-01 Does not apply on Single tire system
Late 6000 & 8000 Series With unit mounted no-till coulter	*C125 Floating Requires C125MTR-81 mount	Will not work with coulter	BSCW1344 Dual BSCW1544 Single Note—not available for 8000 single wheel closing system	Double V closing system uses DCK-01 Does not apply on Single tire system
9800 w/out coulter	C125S-XP C125R-XP BD/UMO1360	UMO-100 requires UMO-MTJ & C125MTR-XP	BSCW1344 Dual BSCW1544 Single Note—not available for 8000 single wheel closing system	Double V closing system uses DCK-01 Does not apply on Single tire system
9800 w/unit mounted coulter	C125R-XP	Will not work with coulter	BSCW1344 Dual BSCW1544 Single Note—not available for 8000 single wheel closing system	Double V closing system uses DCK-01 Does not apply on Single tire system

Planter Model CASE IH

***Will not work if drive shaft is under frame**

****Will not work with pneumatic down pressure**

	Row Cleaner & Mount	Fertilizer Opener	Spiked Closing Wheels	Drag Chain
800 & 900 Series	<p>*BCIH 1360 Floating</p> <p>*C125 Floating With C125MTR-IH mount</p> <p>B1334/892 Pin adjust</p>	<p>UMO-100 BCIH/UMO1360 Row Cleaner Ferti- lizer combo unit</p>	BSCW899	Does not apply
1200 & 1300 Series	<p>*BCIH1360 Floating</p> <p>*C125 Floating w/ C125MTR-IH mount</p> <p>**B1334/1250 Pin adjust</p>	<p>UMO-100 BCIH/UMO1360 Row Cleaner Ferti- lizer combo unit</p>	BSCW899	Does not apply
2000 Series	<p>BCIH1360 Floating Or BD1360 Floating if planter is equipped with HD adaptor CNH part # 48054385</p>	<p>UMO-100 BD/UMO1360 Row Cleaner Ferti- lizer combo unit BD/DUMO1360 Dual Fertilizer com- bo unit Requires 48054385 adaptor</p>	BSCW210	Does not apply